

Mesh Cleaning Kit

Microfibre Soft Mitt | Cleaning & Protection Solution



POWERED BY ALSPEC

2-in-1
Cleaning & Protection
Solution



Non-Toxic
Biodegradable
Eco & User Friendly



Specialized developed to clean & protect your Invisi-Gard mesh

USE DIRECTIONS

1. Mix 5ml of the solution into 4 litres of warm water in a bucket.
2. Soak soft mitt and wring it before cleaning mesh thoroughly.
3. Rinse thoroughly with clean water and dry with clean cloth.



SUGGESTED MAINTENANCE PERIOD TABLE

Environment	Cleaning Interval
Mild <i>Greater than 10km radius from oceanfront or saline bay</i>	Every 6 months
Moderate <i>Within 1km to 10km radius of an oceanfront or saline bay</i>	Every 2 to 3 months
Marine <i>Within 500m to 1km radius of an oceanfront or saline bay</i>	Every 2 to 4 weeks
Severe Marine <i>Within 500m radius of an oceanfront or saline bay</i>	Every 1 to 2 weeks

Alspec Code	Item Description
1409119	INVISI-GARD MESH CARE KIT

FIRST AID INFORMATION

Avoid inhalation.

If swallowed, seek medical advice. Store away from children.

FOR ADVICE, CONTACT THE POISON INFORMATION CENTRE AT 13 11 26 OR A DOCTOR.

KEEP OUT OF REACH OF CHILDREN.

November 2021

Call 1300 ALSPEC (257732)

alspec.com.au

